

Wiring colours and functions used in the two black cables that connect the "Plessey/Skanti TRP 8255 S R" to the outside world

---

Serial control cable. (Command and control)

---

SK1 "Control"	PC (D9F) CU [601] TS1
	RS232: 2400,0,8,1
Red	3 1 = Serial Input: Red.
Shield	Shell 2 = Frame Ground: Pink.
Yellow	2 3 = Serial Output: Yellow.
Blue	5 4 = Serial Ground: Blue.
Green	Not used.
White	Not used.
Black	Not used.

---

TX/RX Data (Audio) cable. (TX/RX AF in/out)

---

PL1 "Data"	CU Line Xfmr board [603]
	Audio: approx 0dBm, Z = 600 Ohm.
Yellow	1 = RX Line Out - White.
Shield (NOT frame)	2 = RX Line Out Gnd Pink.
Green	3 = RX Line Out + Green.
Red	7 = TX Telex In - Red.
Blue	9 = TX Telex In + Black.
White	Not Used.
Black	Not Used.