

3. PREVENTIVE MAINTENANCE

Due to the modern design of the TRP 8250 preventive maintenance can be reduced to a minimum provided the equipment is correctly installed. To ensure maximum performance and minimum repair trouble we recommend you to follow below stated headlines for preventive maintenance.

1. The condition of the battery should be checked at frequent intervals. The battery must always be fully charged and should be topped up frequently with distilled water (liquid should be 5 to 10 mm above the plates).
2. Check the condition of antenna installation, ground connection and cables at regular intervals.
3. Keep antenna feed-through insulators clean and dry.
4. Insure that no objects are obstructing the free airflow through the cooling fins at the back of the TRANSCEIVER UNIT and keep the units free of dust accumulation to prevent overheating.