

CONTENTS

	Page
1	DESCRIPTION
1.1	General Information 1-01
1.1.1	Designation 1-01
1.1.1.1	Available Versions 1-01
1.1.2	Possible Utilization 1-01
1.1.3	General Description 1-01
1.2	Scope of Delivery 1-02
1.2.1	Standard Version 1-02
1.2.1.1	Single Unit 1-02
1.2.1.2	19" Combination 1-02
1.2.2	Special Accessories 1-02
1.2.3	Spare Parts 1-02
1.3	Technical Data 1-03
1.3.1	Electrical Data 1-03
1.3.2	Environmental Conditions 1-04
1.3.3	Dimensions and Weight 1-04
1.4	Technical Description 1-05
1.4.1	Power Supply SV 1275 1-05
1.4.2	Amplifier-Multicoupler VT 1275 H 1-05
2	OPERATING INSTRUCTIONS
2.1	Special Precautions to Prevent Accidents 2-01
2.2	Setting-Up and Taking-Down, Connections 2-01
2.2.1	Mains Connection 220 V or 110 V \pm 10%, 45 to 480 Hz 2-01
2.2.2	Battery Connection 24 V DC (21.5 V to 30 V DC) 2-01
2.2.3	Grounding 2-01
2.2.4	Antenna and Receiver Connections 2-01
2.2.5	Fault Signalling Connection 2-02
2.3	Checks before Commissioning 2-02
2.4	Commissioning and Operation 2-02
2.5	Operation under Arduous Climatic Conditions 2-02
2.6	Care 2-02