

3	MAINTENANCE AND SERVICING BY THE OPERATING STAFF	
3.1	Maintenance	3-01
3.2	Repairs by the Operating Staff	3-01
3.3	Conservation of the Unit During Prolonged Idle Periods	3-01
4	REPAIRS BY SPECIALLY TRAINED PERSONNEL	
4.1	Special Tools, Measuring Equipment and Test Units	4-01
4.2	Functional Principles	4-01
4.2.1	Power Supply SV 1275	4-01
4.2.2	Amplifier-Multicoupler VT 1275 H	4-01
4.2.2.1	High-Pass Filter and Low-Pass Filter	4-01
4.2.2.2	Amplifier	4-01
4.2.2.3	Fault Message	4-02
4.2.2.4	Multicoupler Network	4-02
4.3	Fault Tracing Instructions	4-02
4.3.1	Fault Tracing Table	4-03
4.4	Instructions for Making Repairs	4-04
4.4.1	Removing and Mounting the Subassemblies	4-04
4.4.1.1	Power Supply SV 1275	4-04
4.4.1.2	Amplifier-Multicoupler VT 1275 H	4-04
4.4.2	Dismantling the Modular Assemblies	4-04
4.4.2.1	Power Supply SV 1275	4-04
4.4.2.1.1	Removing the Printed Circuit Board	4-04
4.4.2.2	Amplifier-Multicoupler VT 1275 H	4-05
4.4.2.2.1	Removing the High-Pass and Low-Pass Filter	4-05
4.4.2.2.2	Removing the Printed Circuit Boards	4-05
4.4.3	Recognition of a Defective Transistor	4-05
4.4.4	Testing	4-06
4.4.4.1	Measuring the Gain	4-06
4.4.4.2	Measuring the Intermodulation	4-06
4.4.4.3	Measuring the Sensitivity	4-07
4.4.4.4	Aligning the High-Pass and Low-Pass Filter	4-08
4.4.4.5	Measuring the phase response and gain as a function of frequency (for V 1275 H–P)	
4.5	Illustrations	
Frontispiece	Antenna Multicoupler V 1275 H, H–P	III
Fig. 1	Antenna Multicoupler V 1275 H in Combination with Multicouplers VT 1276 and VT 1277 VU	B 01